


## SPARE PARTS

[www.ecs-electronics.com](http://www.ecs-electronics.com)




Partnr.: DU-014-BB

|                            |                           |
|----------------------------|---------------------------|
| Gebrauchsanleitung (DE)    | (CZ) Uživatelská příručka |
| Mode d'emploi (FR)         | (DK) Brugervejledning     |
| Gebruikershandleiding (NL) | (FI) Käyttöohjeet         |
| User guide (GB)            | (GR) Οδηγός χρήστη        |
| Guía del usuario (ES)      | (NO) Brukerveiledning     |
| Manuale di istruzioni (IT) | (PL) Instrukcja obsługi   |
| Bruksanvisning (SE)        |                           |















## Daihatsu Cuore 2007-



- |                                     |                               |
|-------------------------------------|-------------------------------|
| (DE) Anschluss Steckdose            | (CZ) Objímkový konektor       |
| (FR) Connection de la prise         | (DK) Stikdåse forbindelse     |
| (NL) Contactdoos aansluiting        | (FI) Pistorasia liitäntä      |
| (GB) Socket connection              | (GR) Υποδοχή σύνδεσης         |
| (ES) Conexión de la caja de enchufe | (NO) Tilkobling koblingsboks  |
| (IT) Allaccio zoccolo               | (PL) Połączenie przez gniazdo |
| (SE) Anslutning kontaktdosa         |                               |

| DIN/ISO<br>1724  |           |           |           |         |         |          |         |        |
|------------------|-----------|-----------|-----------|---------|---------|----------|---------|--------|
| P <sub>max</sub> | 21W       | 2x21W     |           | 21W     | 52W     | 3x21W    | 52W     |        |
| (DE)             | Gelb      | Blau      | Weiß      | Grün    | Braun   | Rot      | Schwarz | Grau   |
| (FR)             | Jaune     | Bleu      | Blanc     | Vert    | Marron  | Rouge    | Noir    | Gris   |
| (NL)             | Geel      | Blauw     | Wit       | Groen   | Bruin   | Rood     | Zwart   | Grijs  |
| (GB)             | Yellow    | Blue      | White     | Green   | Brown   | Red      | Black   | Grey   |
| (ES)             | Amarillo  | Azul      | Blanco    | Verde   | Marrón  | Rojo     | Negro   | Gris   |
| (IT)             | Giallo    | Blu       | Bianco    | Verde   | Marrone | Rosso    | Nero    | Grigio |
| (SE)             | Gul       | Blå       | Vit       | Grön    | Brun    | Röd      | Svart   | Grå    |
| (CZ)             | Žlutá     | Modrá     | Bílá      | Zelená  | Hnědá   | Červená  | Černá   | Šedá   |
| (DK)             | Gul       | Blå       | Hvid      | Grøn    | Brun    | Rød      | Sort    | Grå    |
| (FI)             | Keltainen | Sininen   | Valkoinen | Vihreä  | Ruskea  | Punainen | Musta   | Harmaa |
| (GR)             | Κίτρινο   | Μπλε      | Λευκό     | Πράσινο | Καφέ    | Κόκκινο  | Μαύρο   | Γκρι   |
| (NO)             | Gul       | Blå       | Hvit      | Grønn   | Brun    | Rød      | Svart   | Grå    |
| (PL)             | Żółty     | Niebieski | Biały     | Zielony | Brązowy | Czerwony | Czarny  | Szary  |





- DE Gebrauchsanleitung
- FR Mode d'emploi
- NL Gebruikershandleiding
- GB User guide
- ES Guía del usuario
- IT Manuale di istruzioni
- SE Bruksanvisning
- CZ Uživatelská příručka
- DK Brugervejledning
- FI Käyttöohjeet
- GR Οδηγός χρήστη
- NO Brukerveiledning
- PL Instrukcja obsługi

